

PARTS DRAWING



*Please note, when ordering online via our website if the part number is not recognised, please Email spares@hscgroupuk.co.uk or Telephone 0115 946 1988

KEEP THIS BOOKLET FOR FUTURE REFERENCE


📞 Nottingham: 0115 946 1988 • London: 0208 830 3333 🛛 🖂 Nottingham: sales@hscgroupuk.co.uk • London: sean@hscgroupuk.co.uk 🛛 🔀 www.hscgroupuk.co.uk

UNIT 1


From Serial Number: 30803707

ILLUSTRATED PARTS BREAKDOWN

Edizione 2011 Rev. A



B 180 2011 MODEL



Pos.	Code NR	Description
1	4033.016	UPPER SHELL
2	4032.836	GRID
3	4032.815	MOTOR
4	4032.835	MOTOR BRACKET
5	4032.814	FAN
6	4033.028	AIR FLAP
7	4160.646	CABLE PROTECTION
8	4033.132	COMBUSTION CHAMBER
9	4033.015	LOWER SHELL
10	4104.170	CLIP NUT
11	4032.846	FUEL TANK CAP
12	4032.811	HANDLES
13	4032.813	DRAIN PLUG
14	4032.809	AXLE
15	4111.480	WHEEL PLUG
16	4111.072	WHEEL HOLDER
17	4032.094	WHEEL
18	4033.037	TANK
19	4031.163	NOZZLE
20	4160.601	SCREW
21	4110.393	WASHER
22	4032.396	BIFILAR ELECTRODE
23	4110.394	WASHER
24	4033.042	BURNER FLANGE
25	4161.140	ELBOW
26	4033.022	PHOTOCELL
27	4032.883	LIMIT THERMOSTAT
28	4032.885	HT CABLE
29	4111.081	COUPLING
30	4032.789	PUMP
31	4161.501	NIPPLES
32	4032.905	POWER CORD SOLENOID SPOOL
33	4032.947	CABLE PROTECTION

42 4032.771 POWER LINE RFI FILTER 43 4160.639 POP RIVET WITH TERMIN. 4 W 44 4032.816 CAPACITOR 6,3 μf 45 4111.153 POWER CORD 46 4111.119 THERMOSTAT SOCKET 48 4162.467 CAP FOR THERMOSTAT SOCKET 49 4032.850 FUSE (6,3X32) 15A 50 4111.038 STRAIN RELIEF 51 4032.823 ELECTR. COMPONENTS PANEL 52 4100.667 ON/OFF SWITCH			
35 4032.906 FITTING 1/4" 36 4110.356 FUEL FILTER 37 4110.355 FUEL LINE TANK-PUMP 38 4033.038 FUEL PIPE PUMP-TANK 39 4100.541 RUBBER BUSHING 40 4110.032 FUEL LINE 41 4033.017 IGNITION CONTROL ASSEMBL 42 4032.771 POWER LINE RFI FILTER 43 4160.639 POP RIVET WITH TERMIN. 4 V 44 4032.816 CAPACITOR 6,3 μf 45 4111.153 POWER CORD 46 4111.119 THERMOSTAT SOCKET 48 4162.467 CAP FOR THERMOSTAT SOCKET 49 4032.850 FUSE (6,3X32) 15A 50 4111.038 STRAIN RELIEF 51 4032.823 ELECTR. COMPONENTS PANEL 52 4100.667 ON/OFF SWITCH	0 S.	Code NR	Description
36 4110.356 FUEL FILTER 37 4110.355 FUEL LINE TANK-PUMP 38 4033.038 FUEL PIPE PUMP-TANK 39 4100.541 RUBBER BUSHING 40 4110.032 FUEL LINE 41 4033.017 IGNITION CONTROL ASSEMBL 42 4032.771 POWER LINE RFI FILTER 43 4160.639 POP RIVET WITH TERMIN. 4 W 44 4032.816 CAPACITOR 6,3 μf 45 4111.153 POWER CORD 46 4111.119 THERMOSTAT SOCKET 48 4162.467 CAP FOR THERMOSTAT SOCKET 49 4032.850 FUSE (6,3X32) 15A 50 4111.038 STRAIN RELIEF 51 4032.823 ELECTR. COMPONENTS PANEL 52 4100.667 ON/OFF SWITCH	34	4032.854	OIL SUPPLY PIPE
37 4110.355 FUEL LINE TANK-PUMP 38 4033.038 FUEL PIPE PUMP-TANK 39 4100.541 RUBBER BUSHING 40 4110.032 FUEL LINE 41 4033.017 IGNITION CONTROL ASSEMBL 42 4032.771 POWER LINE RFI FILTER 43 4160.639 POP RIVET WITH TERMIN. 4 V 44 4032.816 CAPACITOR 6,3 μf 45 4111.153 POWER CORD 46 4111.119 THERMOSTAT SOCKET 48 4162.467 CAP FOR THERMOSTAT SOCKET 49 4032.850 FUSE (6,3X32) 15A 50 4111.038 STRAIN RELIEF 51 4032.823 ELECTR. COMPONENTS PANEL 52 4100.667 ON/OFF SWITCH	35	4032.906	FITTING 1/4"
38 4033.038 FUEL PIPE PUMP-TANK 39 4100.541 RUBBER BUSHING 40 4110.032 FUEL LINE 41 4033.017 IGNITION CONTROL ASSEMBL 42 4032.771 POWER LINE RFI FILTER 43 4160.639 POP RIVET WITH TERMIN. 4 W 44 4032.816 CAPACITOR 6,3 μf 45 4111.153 POWER CORD 46 4111.119 THERMOSTAT SOCKET 48 4162.467 CAP FOR THERMOSTAT SOCKET 49 4032.850 FUSE (6,3X32) 15A 50 4111.038 STRAIN RELIEF 51 4032.823 ELECTR. COMPONENTS PANEL 52 4100.667 ON/OFF SWITCH	36	4110.356	FUEL FILTER
39 4100.541 RUBBER BUSHING 40 4110.032 FUEL LINE 41 4033.017 IGNITION CONTROL ASSEMBL 42 4032.771 POWER LINE RFI FILTER 43 4160.639 POP RIVET WITH TERMIN. 4 V 44 4032.816 CAPACITOR 6,3 μf 45 4111.153 POWER CORD 46 4111.119 THERMOSTAT SOCKET 48 4162.467 CAP FOR THERMOSTAT SOCKET 49 4032.850 FUSE (6,3X32) 15A 50 4111.038 STRAIN RELIEF 51 4032.823 ELECTR. COMPONENTS PANEL 52 4100.667 ON/OFF SWITCH	37	4110.355	FUEL LINE TANK-PUMP
40 4110.032 FUEL LINE 41 4033.017 IGNITION CONTROL ASSEMBL 42 4032.771 POWER LINE RFI FILTER 43 4160.639 POP RIVET WITH TERMIN. 4 W 44 4032.816 CAPACITOR 6,3 μf 45 4111.153 POWER CORD 46 4111.119 THERMOSTAT SOCKET 48 4162.467 CAP FOR THERMOSTAT SOCKET 49 4032.850 FUSE (6,3X32) 15A 50 4111.038 STRAIN RELIEF 51 4032.823 ELECTR. COMPONENTS PANEL 52 4100.667 ON/OFF SWITCH	38	4033.038	FUEL PIPE PUMP-TANK
414033.017IGNITION CONTROL ASSEMBL424032.771POWER LINE RFI FILTER434160.639POP RIVET WITH TERMIN. 4 W444032.816CAPACITOR 6,3 μf454111.153POWER CORD464111.119THERMOSTAT SOCKET484162.467CAP FOR THERMOSTAT SOCKET494032.850FUSE (6,3X32) 15A504111.038STRAIN RELIEF514032.823ELECTR. COMPONENTS PANEL524100.667ON/OFF SWITCH	39	4100.541	RUBBER BUSHING
42 4032.771 POWER LINE RFI FILTER 43 4160.639 POP RIVET WITH TERMIN. 4 V 44 4032.816 CAPACITOR 6,3 μf 45 4111.153 POWER CORD 46 4111.119 THERMOSTAT SOCKET 48 4162.467 CAP FOR THERMOSTAT SOCKET 49 4032.850 FUSE (6,3X32) 15A 50 4111.038 STRAIN RELIEF 51 4032.823 ELECTR. COMPONENTS PANEL 52 4100.667 ON/OFF SWITCH	40	4110.032	FUEL LINE
43 4160.639 POP RIVET WITH TERMIN. 4 V 44 4032.816 CAPACITOR 6,3 μf 45 4111.153 POWER CORD 46 4111.119 THERMOSTAT SOCKET 48 4162.467 CAP FOR THERMOSTAT SOCKET 49 4032.850 FUSE (6,3X32) 15A 50 4111.038 STRAIN RELIEF 51 4032.823 ELECTR. COMPONENTS PANEL 52 4100.667 ON/OFF SWITCH	41	4033.017	IGNITION CONTROL ASSEMBLY
44 4032.816 CAPACITOR 6,3 μf 45 4111.153 POWER CORD 46 4111.119 THERMOSTAT SOCKET 48 4162.467 CAP FOR THERMOSTAT SOCKET 49 4032.850 FUSE (6,3X32) 15A 50 4111.038 STRAIN RELIEF 51 4032.823 ELECTR. COMPONENTS PANEL 52 4100.667 ON/OFF SWITCH	12	4032.771	POWER LINE RFI FILTER
45 4111.153 POWER CORD 46 4111.119 THERMOSTAT SOCKET 48 4162.467 CAP FOR THERMOSTAT SOCKET 49 4032.850 FUSE (6,3X32) 15A 50 4111.038 STRAIN RELIEF 51 4032.823 ELECTR. COMPONENTS PANEL 52 4100.667 ON/OFF SWITCH	43	4160.639	POP RIVET WITH TERMIN. 4 WAY
46 4111.119 THERMOSTAT SOCKET 48 4162.467 CAP FOR THERMOSTAT SOCKET 49 4032.850 FUSE (6,3X32) 15A 50 4111.038 STRAIN RELIEF 51 4032.823 ELECTR. COMPONENTS PANEL 52 4100.667 ON/OFF SWITCH	14	4032.816	CAPACITOR 6,3 µf
48 4162.467 CAP FOR THERMOSTAT SOCKE 49 4032.850 FUSE (6,3X32) 15A 50 4111.038 STRAIN RELIEF 51 4032.823 ELECTR. COMPONENTS PANEL 52 4100.667 ON/OFF SWITCH	15	4111.153	POWER CORD
49 4032.850 FUSE (6,3X32) 15A 50 4111.038 STRAIN RELIEF 51 4032.823 ELECTR. COMPONENTS PANEL 52 4100.667 ON/OFF SWITCH	16	4111.119	THERMOSTAT SOCKET
504111.038STRAIN RELIEF514032.823ELECTR. COMPONENTS PANEL524100.667ON/OFF SWITCH	18	4162.467	CAP FOR THERMOSTAT SOCKET
514032.823ELECTR. COMPONENTS PANEL524100.667ON/OFF SWITCH	19	4032.850	FUSE (6,3X32) 15A
52 4100.667 ON/OFF SWITCH	50	4111.038	STRAIN RELIEF
· · · · · · · · · · · ·	51	4032.823	ELECTR. COMPONENTS PANEL
53 4032 897 ELECTR COMPONENTS RASE	52	4100.667	ON/OFF SWITCH
	53	4032.897	ELECTR. COMPONENTS BASE



Recycling



ENVIRONMENTAL PROTECTION: Please recycle any unwanted materials as opposed to disposing them as general waste. It is recommended the original is retained and used to store the product when not in use for prolonged periods of time. If this is not applicable ensure the materials are sorted and recycled in accordance with local regulations.



SPECIFICATION CHANGE: It is our policy to continually improve products to ensure these meet the rigours of the industry we serve. Therefore, as such we reserve the right to alter specifications, data, components & parts with-out prior notice.

WARRANTY: Please refer to the manufactures terms & conditions.

IMPORTANT: No liability will be accepted for the incorrect use of this product.

KEEP THIS BOOKLET FOR FUTURE REFERENCE

📞 Nottingham: 0115 946 1988 • London: 0208 830 3333 🛛 🖂 Nottingham: sales@hscgroupuk.co.uk • London: sean@hscgroupuk.co.uk 🛛 🌐 www.hscgroupuk.co.uk